

XE135B spare parts list

Serial No.	Material Type	Material Name	Material No.	Item Description
1	maintenance parts	Oil filter	800151027	XCMG-JL-02001 Oil Filter
2		Fuel Filter	800159613	P505951 Fuel main filter element
3		Oil-water separator filter	800157595	P502424 oil filter element
4		Air cleaner filter	800151034	XCMG-KWL-01301 Air filter element
5		Air cleaner filter	800151033	XCMG-KNL-01301 Air inner filter
6		Back to the oil filter	860149016	XCMG-YHL-02010 oil return filter element
7		Hydraulic oil filter oil	860149017	XCMG-YXL-02010 oil suction filter
8		Pilot filter	860151967	XCMG-XDL-01510 Pilot filter
9	consuming parts	Tooth point	819950044	300T-220 bucket teeth (special use for spare parts of the head)
10		pin	819948374	ZD300LK circlip (for spare parts)
11		spring	819948373	ZD300PN pin (for spare parts)
12		relay	803609933	896-1CH-C/DC24V Relay
13		Power Master Switch	803608695	34B0087 Manual power switch
14		Pressure Switch	803538020	0110-41103-1-043 Pressure switch 1.5MPa
15		Fuel sensor	803504597	FS-005-710 Fuel sensor
16		Level Gauge	803173177	YWZ-150 level gauge
17		Air conditioning belt	800141360	Automobile V belt (with teeth) AV13×1080LI (Gates belt V13×1120)
18		Fuse	803608835	153.5631.560 Insurance film
19		Fuse	803608737	0257020 20A fuse
20		Fuse	803608736	0257015 fuse 15A
21		Fuse	803608735	0257010 Fuse 10A
22		Fuse	803701726	BX2011C-10A fuse
23		Fuse	803600872	BX2011C-15A Insurance film
24		Fuse	803602810	BX2011C-30A Insurance film
25		Lock	802138288	C3-6-028 sliding window lock
26		O-ring	819908911	GB/T3452.1-2005 O-ring 112×7

